

## Screwlift

Manhole cover levelling system



### DESCRIPTION

Manhole cover levelling system

## SPECIFICATION

### General information

Stock code

SCREWLIFT

## NOTES

### PACK CONTENTS (1 SET)

Bolts: 4

Plastic bushes: 4

Allen key: 1

5mm Hex screw bit: 1

## INSTALLATION INSTRUCTIONS

- 1 Insert all of the plastic brushes into the corners of the flange from the underside of the frame.
- 2 Screw the levelling bolts into the brushes from the top side.
- 3 Using a spirit level or a straight edge on top of the frame, wind down the bolts to achieve the correct level to match the ground/ road surface.
- 4 Apply the bedding mortar to the manufacturers' requirements.

1. Wrekin Products Ltd is continually seeking to improve our products and therefore reserves the right to alter product specifications without prior notice.
2. It is the responsibility of all users to satisfy themselves the above data is current.
3. Installation details are available on request.
4. All Wrekin products are supplied subject to our [Terms and Conditions of Sale](#)

