

### **SCREWLIFT**

Simple and rapid manhole frame levelling system. Simply push the bushes into the holes in the flange and adjust the levelling screws to the required height.



CHARACTERISTIC VALUE

**Description** 

Simple and rapid manhole frame levelling system. Simply push the bushes into the holes in the flange and adjust the levelling screws to the required height.

### **SPECIFICATION**

#### **GENERAL INFORMATION**

Stock code

SCREWLIFT

#### **NOTES**

# **PACK CONTENTS (1 SET)**

Bolts: 4

Plastic bushes: 4 Allen key: 1

5mm Hex screw bit: 1

## **INSTALLATION VIDEO**







Tel: 01543 440 440 Fax: 01543 440 444 info@wrekinproducts.com wrekinproducts.com



# **INSTALLATION INSTRUCTIONS**

- ▶ Insert all of the plastic brushes into the corners of the flange from the underside of the frame.
- Screw the levelling bolts into the brushes from the top side.
- ▶ Using a spirit level or a straight edge on top of the frame, wind down the bolts to achieve the correct level to match the ground/ road surface.
- Apply the bedding mortar to the manufacturers' requirements.



- Wrekin Products Ltd is continually seeking to improve our products and therefore reserves the right to alter product specifications without prior notice.
- It is the responsibility of all users to satisfy themselves the above data is current.
- ▶ All values stated are nominal within 2.5% tolerance.
- ▶ Installation details are available in the knowledge base.
- ▶ All Wrekin products are supplied subject to our <u>Terms</u> and <u>Conditions of Sale.</u>







