

KEY

- 1 Root-tex 30 geotextile
- 2 200mm deep ProtectaWeb tree root protection system infilled with 20/40 Clean angular Stone to BS EN 13242 / EN 12620
- 3 Soil graded to edging (if required)
- 4 Root-tex 10 geotextile
- 5 4/20mm Surcharge 50mm max
- 6 Existing tree

NOTE

Remove top 50mm of vegetation by hand.

More may be removed at the descretion of your Tree Officer.

